

Formula and Reference Sheet

International System of Units (SI)

| Prefix | Symbol | | Value | |
|--------|--------|------------|---------------|--------------------|
| giga- | G | 10^9 | 1,000,000,000 | one billion |
| mega- | M | 10^6 | 1,000,000 | one million |
| kilo- | k | 10^3 | 1,000 | one thousand |
| (none) | (none) | 10^0 | 1 | one |
| centi- | c | 10^{-2} | .01 | one one-hundredth |
| milli- | m | 10^{-3} | .001 | one one-thousandth |
| micro- | μ | 10^{-6} | .000001 | one one-millionth |
| nano- | n | 10^{-9} | .000000001 | one one-billionth |
| pico- | p | 10^{-12} | .000000000001 | one one-trillionth |

Technician Exam

Length of 1/2 wavelength antenna:

$$\text{Length (feet)} = \frac{468}{\text{Frequency (in MHz)}}$$

Length of 1/4 wavelength antenna:

$$\text{Length (feet)} = \frac{234}{\text{Frequency (MHz)}}$$

Ohm's law:

$$V = I * R, \quad I = \frac{V}{R}, \quad R = \frac{V}{I}$$

where:

V is the voltage in Volts (V), I is the current in Amps (A), R is the resistance in Ohms (Ω)

Power formulas:

$$P = V * I, \quad I = \frac{P}{V}, \quad V = \frac{P}{I}$$

where:

P is the power in Watts (W), V is the voltage in Volts (V), I is the current in Amps (A)

General Exam

Standing wave ratio:

$$SWR = \frac{\text{highest impedance}}{\text{lowest impedance}}$$

Equal-value resistors in series:

$$R_t = \frac{R_i}{n}$$

Equal-value resistors in parallel:

$$R_t = \frac{R_i}{n}$$

Resistors in parallel:

$$\frac{1}{R_t} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3}$$

Inductors in series:

$$L_t = L_1 + L_2$$

Equal-value inductors in parallel:

$$L_t = \frac{L_i}{n}$$

Capacitors in series:

$$\frac{1}{C_t} = \frac{1}{C_1} + \frac{1}{C_2} + \frac{1}{C_3}$$

Equal-value capacitors in series:

$$C_t = \frac{C_i}{n}$$

Capacitors in parallel:

$$C_t = C_1 + C_2 + C_3$$

Transformers:

$$E_s = E_p * \left(\frac{N_s}{N_p}\right) \quad \frac{N_p}{N_s} = \sqrt{\frac{Z_p}{Z_s}}$$

RMS voltage:

$$V_p = \frac{V_{RMS}}{0.707}, \quad V_{RMS} = V_p * 0.707 \quad V_{pp} = V_p * 2$$

Power:

$$P = E * I \quad P = \frac{E^2}{R} \quad P = I^2 * R \quad E = \sqrt{P * R}$$

Peak envelope power:

$$PEP = \frac{V_{RMS}^2}{R}$$

Decibel math:

$$loss\ factor = 10^{\left(\frac{-loss(in\ db)}{10}\right)} \quad percent\ loss = (1 - loss\ factor) * 100$$

Frequency modulation:

$$bandwidth = 2 * (D_{MAX} + M_{MAX})$$

Upconverter:

$$multiplier = \frac{transmitted\ frequency}{lower\ frequency}$$

$$lower\ frequency\ maximum\ deviation = \frac{transmitted\ frequency\ maximum\ deviation}{multiplier}$$

Extra Exam

Antenna gain in dBd vs dBi:

$$\text{gain of antenna in dBd} = \text{gain of antenna in dBi} - 2.15 \text{ dB}$$

Effective radiated power:

$$ERP = \text{transmitter power} * 10^{\left(\frac{\text{gain in dB}}{10}\right)}$$

Length of transmission line:

$$\lambda = \frac{c * \text{velocity factor}}{f}$$

Forward and reflected power:

$$\text{power to load} = \text{forward power} - \text{reflected power}$$

Third-order intermodulation products:

| Formula | Formula Solve for f_2 |
|--------------------|-----------------------------|
| $f_i = 2f_1 + f_2$ | $f_2 = f_i - 2f_1$ |
| $f_i = 2f_1 - f_2$ | $f_2 = 2f_1 - f_i$ |
| $f_i = 2f_2 + f_1$ | $f_2 = \frac{f_i - f_1}{2}$ |
| $f_i = 2f_2 - f_1$ | $f_2 = \frac{f_i + f_1}{2}$ |

Operational amplifiers:

$$V_{OUT} = -V_{IN} * \frac{R_F}{R_1} \qquad A_V = \frac{R_F}{R_1}$$

Image response frequencies:

$$f_{img1} = f_{RF} - 2 * f_{IF} \qquad f_{img2} = f_{RF} + 2 * f_{IF}$$

Noise floor:

$$BNF = NF + 10 * \log(BW)$$

where:

BNF is the bandwidth noise floor (the noise for the entire received bandwidth) (in dBm)

NF is the 1-Hz noise floor (in dBm/Hz)

BW is the receive filter bandwidth (in Hz)

Time constant (all components in parallel):

$$R_t = \frac{R_i}{n} \quad C_t = C_1 + C_2 \quad T = R * C$$

Parts per million:

$$\text{maximum error} = \text{measurement} * \text{accuracy}$$

Resonant frequency:

$$f_R = \frac{1000}{2\pi * \sqrt{LC}}$$

where:

L in μH

C in pF

f_R in MHz

Half-power bandwidth:

$$\text{half - power bandwidth} = \frac{f_R}{Q}$$

Transformer turns #1:

$$N = 100 * \sqrt{\frac{L}{A_L}}$$

where:

L in μH

A_L in $\mu H/100$ turns

Transformer turns #2:

$$N = 1000 * \sqrt{\frac{L}{A_L}}$$

where:

L in mH

A_L in $mH/1000$ turns

Frequency modulation:

$$\text{deviation ratio} = \frac{D_{MAX}}{M_{MAX}} \quad \text{modulation index} = \frac{\text{frequency deviation}}{\text{modulating frequency}}$$

Inductive and capacitive reactances:

$$X_L = 2\pi fL \quad X_C = \frac{1}{2\pi fC} \quad X = X_L - X_C$$

Phase angle:

$$\theta = \arctan\left(\frac{X}{R}\right)$$

Power factor:

$$\text{power factor} = \cos(\theta) \quad \text{apparent power} = V_{RMS} * I$$

$$\text{true power} = \text{apparent power} * \text{power factor}$$

$$P = I^2 * R$$